




Survivor Powerbank 10000 PD20W

Quick guide

420-91



**Survivor Powerbank
10000 PD20W**

Capacity: 10000 mAh / 37 Wh

USB-C Input: 5V/3A, 9V/2A, 12V/1.5A PD (18W max)

USB-C Output: 5V/3A, 9V/2A, 12V/1.67A PD (20W max)

USB-A Output: 4.5V/5A, 5V/4.5A, 9V/2A, 12V/1.5A PD (22.5W max)

Wireless charging: 15W max

Product weight: 386g

Item no. 420-91

www.sandberg.world

Made in China

Sandberg A/S
Bregnerødvej 133D,
3460 Birkerød, Denmark



NOTE: For optimal battery performance, we recommend fully discharging and recharging the power bank at least once every three months.



**Double
Quality
Tested**

5

**Years
Warranty**

Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty


www.sandberg.world

Support: <http://helpdesk.sandberg.world>




For information on handling electronic waste, see www.sandberg.world/weee




Product overview




1. USB output
2. USB-C input & output
3. Flashlight
4. Strap mount
5. LED indicators
6. Power button
7. Wireless charging




Charge Powerbank



Charge devices



Example of use




Press once to check
the capacity status


Flashlight procedure




1. Long press to
turn on flashlight



2. Press once more
for caution light



3. Press once more
for SOS



4. Press once again
shift to flashlight



5. Long press to
turn off flashlight